

Product Information Bulletin

| |
|-----------|
| September |
| 2014 |

FABGRIP HI-TAC 2007 COMMERCIAL VINYL ADHESIVE

DESCRIPTION:

Fabgrip 2007 is a premium, water based, high performance semi P.S. vinyl adhesive. 2007 was designed for bonding most types of homogeneous & heterogeneous sheet vinyl, to most common interior sub-floors.

CHARACTERISTICS

- * Water Based
- * Non Flammable
- * Aggressive tack
- * Excellent bonding
- * Economical
- * Can be heat reactivated
- * Spreads easily
- * Excellent ageing resistance
- * Coverage; 5m²/ltr
- * Available in: 15ltr, 4ltr & 1ltr pails

SURFACE PREPARATION:

All sub-floor surfaces shall be dry, smooth, sound and clean, free of wax, grease and all other contaminants that inhibit adequate adhesion to the sub-floor. The sub-floor must also be free from hydrostatic pressure or capillary action. The adhesive should not be used in excessive cold or hot conditions i.e. below 8°C or above 28°C.

It is recommended that highly porous timber or concrete sub-floor surfaces be primed with Primer 44 and allowed to cure before applying adhesive. Uneven or damaged floors should be repaired with a cementitious levelling compound.

Timber sub-floors should be tested with an appropriate electrical resistance meter. The timber sub-floor should contain a maximum moisture content of 12%. Particle board flooring requires sanding to remove the wax sealer, prior to the use of this adhesive. All concrete sub-floors should be tested for relative humidity (RH) prior to surface priming or application of adhesive. Ensure the RH (use insitu probe method ASTM F2170 current version) of the concrete sub-floor does not exceed 75%. Also ensure the surface pH of the concrete sub-floor is less than 9. Burnished concrete sub-floors must be ground back to allow for sufficient porosity and adhesion to the sub-floor.

If the sub-floor exceeds the recommended RH & pH levels, sufficient remediation is required prior to the use of this adhesive. All sub-floors should in accordance with current Australian Standard installation practices.

APPLICATION:

With a 1.6 x 1.6 x 1.6mm "V" notched trowel apply an even coat to the surface. Spread only sufficient adhesive to an area, and do not allow the adhesive to form a skin before laying the sheet vinyl. Install the floor-covering onto the tacked up adhesive. Complete the installation according to the manufacturer's instructions, ensuring the installation is rolled in both directions with the recommended roller, prior to the adhesive setting. Do not allow heavy traffic for 24 hours. The product can be re-activated for up to 5 days after the installation.

CLEAN UP:

Clean tools and equipment immediately with warm soapy water. To remove dried adhesive, use Holdfast Super Cleaning Solvent with care.

CAUTION

Do not allow adhesive to freeze, unaffected by freezing when dry. This adhesive has a shelf life of 12 months from date of manufacture providing the adhesive is unopened and stored undercover at 20°C.

VENTILATION

Always make sure that there is adequate ventilation when using this adhesive.

CONDITIONS OF SALE: contain a limited warranty against manufacturing defects.

NOTICE TO THE PURCHASER

All statements and technical information contained herein are based on tests we believe to be reliable but the accuracy thereof is not guaranteed. Users assume all risk and liability resulting from the use of this product and must confirm the suitability thereof by their own tests.

CONTACT POINT: Technical Manager
TELEPHONE: (03) 9797 1888