

RLA MS TIMBER FLOORING ADHESIVE

Solvent & Isocyanate Free



PRODUCT DESCRIPTION:

RLA MS Timber Flooring Adhesive is a single-part, permanently flexible solvent and isocyanate free MS timber flooring adhesive.

FEATURES AND BENEFITS:

- Non Flammable.
- Green Star Compliant
- Green TAG Certified
- Solvent & Isocyanate free.
- Will not re-emulsify with water contact.
- Stands up well under trowel
- Easy to Apply

FOR BONDING:

MS Timber Flooring Adhesive is recommended for bonding, Solid Timber Flooring, Parquet Flooring and Engineered Timber Flooring to Concrete and Timber Substrates. MS Timber Flooring Adhesive is also recommended for bonding approved acoustic underlays to most common subfloors.

SURFACE PREPARATION:

Subfloors must be dry, sound, smooth, clean and in accordance with the relevant Floorcoverings Australian Standards.

Subfloors must also be free of wax, grease, oil, polishes, old adhesive, curing compounds, high levels of moisture and any other surface contaminants that may affect adhesion. If mechanical preparation is required prepare the floor using recommended preparation methods such as shot blasting, scarifying, diamond grinding, to provide a roughened, clean, sound, solid and open porous surface.

It is recommended that highly absorbent concrete subfloors be primed with RLA PU 95 Vapour Barrier prior to the application of adhesive. The minimum subfloor temperature before commencing installation should be 10°C Do not use solvents, or acid etching to clean the subfloor. All concrete subfloors must be tested for moisture content. Relative humidity readings should be determined as per ASTM F2170. Ensure the relative humidity (RH) is below 85% (tested as per ASTM F2170 insitu probe method). If the RH of the sub-floor is above 85% we recommended the use of RLA Two Part Epoxy Moisture Barrier or RLA Single Part Polyurethane Vapour Barrier. The minimum subfloor temperature before commencing surface preparation and adhesive application is 10°C. Indentations and uneven concrete subfloors should be treated with the RLA range of levelling compounds and be in accordance with manufacturer's recommendations. Where temperatures are less than 10°C or greater than 30°C are encountered, contact our technical staff for advice.

MOISTURE PROTECTION:

Concrete slabs can be a source of excess moisture. To prevent moisture migration, apply Two coats RLA Two Part Epoxy Moisture Barrier ensuring the second coat is applied perpendicular to the direction of application of the first coat. Alternatively RLA PU 95 Single Part Polyurethane Vapour Barrier. Application of Timber Flooring Adhesive onto RLA Moisture or Vapour Barrier. Ensure the adhesive is applied onto the Moisture Barrier within 4 days after the application of Moisture Barrier has taken place and cured. Ensure the Barrier is clean and free from dirt, dust and any other contaminant that may affect adhesion. Please refer to the Product Data Sheets for further information and application instructions .

CONCRETE SUBSTRATES:

Subfloors must be dry, sound, smooth, clean, any contaminants that may affect adhesion and in accordance with the relevant Floorcoverings Australian Standards. All concrete subfloors must be tested for moisture content before the application adhesive, primers and barriers.

Indentations and uneven concrete subfloors should be treated with the RLA range of levelling compounds and be in accordance with manufacturer's recommendations.

TIMBER SUBSTRATES:

Timber flooring must be solid, sound, clean and free from wax, oil, free from gaps and securely fixed and in accordance with the Timber Flooring Manufactures Instructions and relevant Australian Standards.

Timber Flooring may be coated with a resin waterproof protective layer.

This layer can act as a bond breaker and can affect adhesion to applied finishes, it should be removed by sanding the subfloor before application of timber flooring underlayment.

It is recommended for the Installation of timber flooring onto timber substrates, Timber Flooring is nailed/secretly fixed in combination with application of adhesive.

Please ensure adequate cross-flow ventilation and that the minimum height clearance between earth and the timber flooring is in accordance with the relevant Australian Standards. Failure to have adequate ventilation can result moisture build up under the subfloor and can compromise the installation of underlayment and Floorcoverings.

APPLICATION:**BONDING ACOUSTIC UNDERLAY TO THE SUB-FLOOR:**

Apply the adhesive evenly with a 2-3mm V notched trowel (2-3mm notched trowel dependant on underlay type) at a rate of approx. 2 m² per litre. Please refer to the underlay or timber manufacturer's instructions for specific trowel size. Install the underlay into the wet adhesive film and ensure transfer occurs between the adhesive film and the underlay. Roll the underlay with a suitable roller to ensure a minimum 100% transfer rate of adhesive film is achieved between the underlay and subfloor. Allow the adhesive to dry for 24 hours prior to installing the floor-covering.

BONDING TIMBER FLOORING SYSTEMS TO ACOUSTIC UNDERLAY:

Apply adhesive evenly with a 3-5mm V notched trowel - please refer to the timber manufacturer's instructions for specific trowel size at a rate of approx. 1 – 1.2 m² per litre. Install the timber flooring into the wet film of adhesive and ensure transfer occurs between the adhesive film and the timber flooring. A minimum of 100% (Transfer) contact between the underlay and timber flooring is required and maintain full contact with adhesive until full cure is achieved. For best results timber flooring should be installed within 30 minutes of the adhesives application.

CONCRETE & CEMENTITIOUS SUBSTRATES:

Subfloors must be dry, sound, smooth, clean, any contaminants that may affect adhesion and in accordance with the relevant Floorcoverings Australian Standards. Apply adhesive evenly with a 4-5mm V notched trowel - please refer to the timber manufacturer's instructions for specific trowel size at a

Version: 1.0

Issue date: 30/08/2023

RLA Polymers Pty Ltd ACN 004 709 915

Head Office
215 Colchester Road
Kilsyth, Victoria, 3137
Tel: 1800 242 931

New South Wales
363 Wentworth Ave
Pendle Hill, N.S.W, 2145

Queensland
57 Fulcrum Street
Richlands, QLD, 4077

South Australia
Unit 2/7 Berger Road
Wingfield, SA, 5013

Western Australia
24 Hanwell Way
Bassendean, W.A, 6054
Tel: 08 9279 8911

rate of approx. 1 – 1.2 m² per litre. Install the timber flooring into the wet film of adhesive and ensure transfer occurs between the adhesive film and the timber flooring. A minimum of 100% (Transfer) contact between the substrate and timber flooring is required and maintain full contact with adhesive until full cure is achieved. For best results timber flooring should be installed within 30 minutes of the adhesives application.

TIMBER FLOORING SUBSTRATES:

Subfloors must be dry, sound, smooth, clean, any contaminants that may affect adhesion and in accordance with the relevant Floorcoverings Australian Standards. Apply adhesive evenly with a 4-5mm V notched trowel - please refer to the timber manufacturer's instructions for specific trowel size at a rate of approx. 1 – 1.2 m² per litre. Install the timber flooring into the wet film of adhesive and ensure transfer occurs between the adhesive film and the timber flooring. A minimum of 100% (Transfer) contact between the substrate and timber flooring is required and maintain full contact with adhesive until full cure is achieved. Do not allow heavy traffic for 24 hours. Sanding can commence 3 to 7 days after the completion of the entire installation. Please note: Sanding times may vary due to climatic conditions please check with the manufacture.

CURE TIME:

Cure times can vary substantially and are dependent on weather conditions such as temperature and humidity. Typically, MS will form a firm skin in two hours and cure in approximately 24 hours. Hotter and more humid conditions will increase the rate of cure and decrease the skin time, whereas colder climates and lower humidity will decrease cure times and increase skin times

CLEAN UP:

Clean tools and equipment immediately after use with a suitable solvent such as white spirits or alternatively Citrus based RLA Handy Wipes. Cured MS Timber Flooring Adhesive can be removed by mechanical means or with RLA Handy Wipes.

COVERAGE:

2-3mm V notched trowel notched trowel will achieve approximately 2 square metres per litre. 4-5mm V notched trowel notched trowel will achieve approximately 1-1.5 square metres per litre

CONTAINER SIZES:

10 litre/ 15kg containers and 600 gram sausages

SHELF LIFE / STORAGE:

12 months when stored in original unopened packaging
To be stored in a dry area off the ground.

SAFETY & HANDLING:

A Safety Data Sheet is available on request.
Product is classified as NON-DANGEROUS GOODS.
According to the WHS Regulations and the ADG Code.

First Aid:

In use, please ensure that Occupational Health and Safety requirements are observed.
Eyes: Irrigate with water for 10 minutes and see a doctor.
Skin: Wash off with warm water and soap.
If swallowed, give plenty of water. Do not induce vomiting. Seek medical attention.

Version: 1.0

Issue date: 30/08/2023

RLA Polymers Pty Ltd ACN 004 709 915

Head Office
215 Colchester Road
Kilsyth, Victoria, 3137
Tel: 1800 242 931

New South Wales
363 Wentworth Ave
Pendle Hill, N.S.W, 2145

Queensland
57 Fulcrum Street
Richlands, QLD, 4077

South Australia
Unit 2/7 Berger Road
Wingfield, SA, 5013

Western Australia
24 Hanwell Way
Bassendean, W.A, 6054
Tel: 08 9279 8911

PRECAUTIONS:

- Please ensure timber flooring is placed into the Wet Film of adhesive and apply sufficient pressure to ensure transfer occurs between the adhesive film and floorcovering.
- A minimum of 100% (Transfer) contact between the substrate and the back of each individual piece of timber is required and maintain full contact with adhesive until full cure is achieved after a minimum of 24 hours (mechanical fixing or weighing down is recommended)
- Application of Timber Flooring Adhesive directly onto RLA Moisture or Vapour barrier ensure the adhesive is applied onto the Moisture Barrier within 4 days after the application of Moisture Barrier has taken place and cured.
- Do not walk on laid matting during the first four hours after installation. Avoid air entrapment when making the bond or filling joints. For application details of timber flooring systems, contact the timber flooring Page 4 of 5 manufacturer. Care should be taken to prevent any reaction or damage pre finished timber coatings.
- Do not use adhesive in excessive hot or cold conditions i.e. below 10°C or above 30°C
- This adhesive will not stand up to hydrostatic pressure or capillary action.
- Ensure your trowel is notched to the manufacturer's recommendations at all times.
- Timber flooring systems must be acclimatised, refer to the timber flooring manufacturers recommendations, prior to the use of this adhesive.
- If in doubt regarding suitability of adhesive, always contact the manufacturer.
- Always follow manufacturer's instructions.
- Do not apply over acrylic or PVA primers/sealers.
- Not recommended to be used in totally confined spaces as requires atmospheric moisture to cure properly.
- Do not expose to water or alcohol based cleaners before full cure.

- Must be fully cured before sanding, allow a minimum of 72 hours.
- Compatibility tests must be first carried out. Due to many forms of timber flooring available today, preliminary adhesion testing should be undertaken by the installer to confirm adhesion. RLA Polymers can assist on large projects.
- Do not apply over dense burnished concrete surfaces without abrading first to obtain a mechanical key for the adhesive to bond to.

WARRANTY STATEMENT:

RLA Polymers guarantees this product against manufacturing defects and guarantees it to be manufactured to our published specification. We certify that when fully cured this product is suitable for use and will perform as described in our technical data sheet or other published materials. RLA Polymers will replace product free of charge when purchased from any legally verifiable source, and where product is proven to have been stored, handled and install according to instructions published on our packaging and within the stated shelf life. The Installation of all materials must be carried out in accordance with the relevant Australian Standard and the Floorcovering Manufacturers instructions and the floorcoverings must have been subject to normal traffic conditions. Warranty doesn't not apply if damage, loss, failure to follow instructions or other circumstances are out of our control. Sufficient time and access to investigate any complaint must be accorded to RLA Polymers. The consumer is responsible for any expenses incurred in making a claim. A claim form can be requested by:
Phone: 1800 242 931
Email: info@rlapolymers.com.au
Mail: 215 Colchester Road Kilsyth Victoria 3137 (attention Customer Service)

Version: 1.0

Issue date: 30/08/2023

RLA Polymers Pty Ltd ACN 004 709 915

Head Office
215 Colchester Road
Kilsyth, Victoria, 3137
Tel: 1800 242 931

New South Wales
363 Wentworth Ave
Pendle Hill, N.S.W, 2145

Queensland
57 Fulcrum Street
Richlands, QLD, 4077

South Australia
Unit 2/7 Berger Road
Wingfield ,SA, 5013

Western Australia
24 Hanwell Way
Bassendean, W.A, 6054
Tel: 08 9279 8911

AUSTRALIAN CONSUMER LAW:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits under our warranty are in addition to other rights and remedies available to the consumer under the law in relation to the goods and services to which the warranty relates.

DISCLAIMER:

All Statements and technical information contained herein are based on tests we believe to be reliable but the accuracy thereof is not guaranteed. Users assume all risk and liability resulting from the use of the product and must confirm the suitability thereof by their own tests. Conditions of Sale contain a limited warranty against manufacturing defects.

Issued: July 2023

Version: 1.0

Issue date: 30/08/2023

RLA Polymers Pty Ltd ACN 004 709 915

Head Office
215 Colchester Road
Kilsyth, Victoria, 3137
Tel: 1800 242 931

New South Wales
363 Wentworth Ave
Pendle Hill, N.S.W, 2145

Queensland
57 Fulcrum Street
Richlands, QLD, 4077

South Australia
Unit 2/7 Berger Road
Wingfield ,SA, 5013

Western Australia
24 Hanwell Way
Bassendean, W.A, 6054
Tel: 08 9279 8911